


HOMELITE®

PART NO. 17767
Printed in U.S.A.
Dealer Price \$1.00

SERVICE GUIDE

XL®, XL-2 and Super 2 Chain Saws



HOMELITE **TEXTRON**

Homelite Division of Textron Inc.

Courtesy of undee70ss
Do Not Sell or Reproduce

PREFACE

This manual contains detailed instructions for the disassembly and reassembly of the XL®, XL-2 and Super-2 chain saws. Read this manual thoroughly before beginning any repairs to the saw. The troubleshooting chart is provided as an aid in the diagnosing of troubles before actual disassembly and repair of the saw is begun. Note all safety precautions to be taken during repairs.

Homelite also offers a SHOP SERVICE MANUAL #23855-5 that explains in depth such areas as carburetion, ignition, two-cycle engine theory, and bar and chain maintenance. The SHOP SERVICE MANUAL is available through your Homelite dealer or by sending a check for \$7.50 to:

Homelite Division of Textron Inc.
14401 Carowinds Boulevard
P.O. Box 7047
Charlotte, North Carolina 28217
Attn: Service Department

CONTENTS

Disassembly Section	Page 4
Reassembly Section	Page 9
Ignition Section	Page 10
Exhaust System Section	Page 11
Automatic Oiler Section	Page 12
Engine Troubleshooting Section	Page 15
Torque Specifications	Page 18
Engine Specifications	Page 19

DISASSEMBLY SECTION




FIGURE 1

Remove the screw at the top of the handlebar and the four screws securing the starter housing to the engine housing. Lift the starter housing and the handlebar off the engine.

STARTER REPAIR




FIGURE 2

If the rope is to be replaced, cut the rope below the grip. This will immediately relieve the spring tension. Otherwise, the spring tension must be relieved by looping the rope as shown in Figure 3 and winding the pulley counter-clockwise. Remove the screw which holds the pulley to the housing.

WARNING

Put on safety glasses and gloves before removing the pulley.

Grasp the toothed pulley hub and pull the pulley out about a half-inch or the width of your finger. Using a thin bladed screwdriver, insert it between the pulley and the housing

to free the pulley from the spring. Push the spring coils into the housing.

CAUTION

If you lift the pulley too far out before detaching the spring, the coils may fly apart. They are difficult to rewind.

Replace the recoil spring if broken or bent. If the inner spring loop has been straightened so that it does not engage the pulley, bend the loop until it is curved enough to engage the pulley.

Replace necessary parts and lightly grease the pulley post before reassembly. Refer to Figure 3 to properly tension recoil spring.




FIGURE 3

Note the rounded notch in the edge of the pulley. Pull out the grip about one foot and hold the pulley to keep it from rewinding. Turn the pulley to locate the notch at the rope

entry hole in the housing. Hook a loop of rope between the housing and the pulley. Grasp the loop and wind two turns in a clockwise direction. Place a thumb on the pulley to keep it from turning. Pull the rope through the hole.

NOTE

When reassembling starter to engine housing, place pulley against rotor while pulling the starter rope a short distance until the pulley engages the pawls. Replace fastening screws securely.

REMOVE ENGINE FROM HOUSING




FIGURE 4

Remove plastic filter cover. Remove the switch wire from module. Remove the spark plug.




FIGURE 5

The muffer may be removed at this time. A single screw secures the muffer to the cylinder.

NOTE

Early models used a 10-24 x 1/2" hex cap screw not visible from the outside. A 9/64" Allen wrench must be inserted through the hole in the muffer cap to remove this screw.




FIGURE 6

Remove the four screws (two on top and two on bottom) that fasten the engine housing to the crankcase. These screws may be Torx head screws with a screwdriver slot. A Torx bit (Homelite #24982-01 or Torx #TX25) may be necessary to remove these screws.




FIGURE 7

Remove the engine from the housing. The throttle rod connecting the carburetor to the throttle lever will separate from the lever when the engine separates from the housing.

NOTE

It is not necessary to remove the throttle cover unless it is to be serviced.

DISASSEMBLING ENGINE




FIGURE 8

Before removing the fuel and oil tubes from their fittings, mark each tube for reassembly purposes. Use a screwdriver to push the tubes from their fittings.




FIGURE 9

Remove the air filter and filter support. Use a 5/16" socket to remove the two screws that secure the carburetor to the crankcase. It may be necessary to gently tap the carburetor to break it away from the manifold. Repeat this to free the manifold from the crankcase.




FIGURE 10

To remove the sprocket and drum, remove the crankshaft nut using a 1/2" socket. Early models used a tru-arc ring to secure the sprocket. This ring must be expanded and lifted out of the shaft groove. On early models, only one washer was used.

CAUTION

Wear eye protection when removing this retaining ring. The ring is under tension and may release prematurely.

NOTE

Do not reuse the retaining ring. Install a new ring with the curved edge toward the sprocket.




FIGURE 11

When removing the clutch it will be necessary to hold the crankshaft to keep it from turning. To do this rotate the shaft until the piston reaches its lowest point of travel. Insert 2"-3" of starter rope into the cylinder (as shown). Slowly turn the shaft until it locks. Using a spanner wrench (Homelite A-93791) and a 13/16" socket, turn the clutch in the direction noted on the clutch.




FIGURE 12

With the shaft locked, use a 1/2" socket to remove the rotor nut. Some models may require a 3/8" socket. The module may be removed at this time, if necessary. Use a 1/4" socket.




FIGURE 13

Install rotor tool (Homelite #A-24747-A) as shown. Tighten the center screw until the rotor loosens. Remove points and condenser if necessary.




FIGURE 14

Remove the four screws which hold the crankcase to the cylinder. Tap the crankcase with a plastic hammer to break the Silastic seal between the mating surfaces. Once this is done, remove the crankshaft assembly.




FIGURE 15

The piston may be removed from the connecting rod by placing a small screwdriver or awl in the notch located on the rotor side of the piston. Pry out the piston pin retaining ring and push out the piston pin.



FIGURE 16

The crankshaft needle bearings are retained in their cage by grease. When the bearings are removed they may fall out of the cage. In order to prevent this, wrap a small piece of paper around the shaft and slide the bearing over the paper. Remove the paper and bearing together. This will hold the needles in place. The crankshaft, connecting rod and connecting rod bearings must be replaced as a complete assembly.



FIGURE 17

To remove the throttle assembly cover, insert a wide blade screwdriver between the rear of the cover and the engine housing. Grasp the rear trigger and twist the screwdriver handle while pushing it forward. Care should be taken not to break the cover tab. Holding the rear trigger will prevent the spring-loaded throttle rod from popping out. On saws having only a single trigger, remove the screw in the rear of the cover and lift the cover off.



FIGURE 18

This figure shows the throttle levers and linkage properly assembled.

REASSEMBLY SECTION

Reverse the above procedure to reassemble the saw. Follow the special instructions given below to correctly reassemble the saw.

CRANKCASE AND CYLINDER AREA

The piston must be assembled to the connecting rod so that the piston ring gap is opposite the exhaust port.

1. Install the thrust washer with the flanged (or raised) side of the washer facing outward.
2. Install the bearings with the lettered (or flat) side facing outward.
3. Lubricate shaft seals with oil before installing onto shaft. After assembling the powerhead, the outer seal surface must be flush with the cylinder and crankcase.
4. Clean the cylinder and crankcase mating surfaces thoroughly.
5. Apply a film of oil to the cylinder bore before inserting the piston.
6. Apply a very light coat of Silastic sealant (Homelite #24823) to the cylinder and crankcase mating surfaces, including the bearing bore.
7. Assemble the cylinder to the crankcase. Secure but *do not* tighten the 4 crankcase screws. Gently tap each end of the crankshaft with a plastic hammer. This will establish "end play" in the shaft. The saw will bind and will not run without end play. Tighten all 4 screws.
8. **IMPORTANT:** Refer to the "Torque Specification Section" before tightening each fastening part.



FIGURE 19

ENGINE HOUSING AREA



FIGURE 20

Note that the throttle rod has a bend in each end. One of the two bends is closed more than the other (as shown on the bottom portion of Figure 20). This end of the rod will be placed into the carburetor lever.




FIGURE 21

Slide the engine halfway into the housing. Align the throttle rod with the hole in the plastic throttle lever. Push the engine into the housing.

NOTE

The spark plug lead must be routed underneath the first two cylinder fins. Do not route it between the rear of the cylinder and engine housing.

IGNITION SECTION

TROUBLESHOOTING CHART FOR IGNITION SYSTEM

SYMPTOM: NO SPARK AT THE SPARK PLUG

Possible Cause

Spark plug fouled
Electrode gap incorrect
Spark plug wire damaged
Faulty switch
Breaker point contacts burned
Breaker point gap incorrect
Rotor air gap incorrect

Remedy

Clean and regap spark plug.
Regap spark plug.
Inspect and replace.
Disconnect switch wire and test for spark.
Inspect, clean and regap or replace.
Regap to .015".
Regap to .015".




FIGURE 22

To check for ignition spark, first remove the spark plug from the cylinder. Check that the electrode gap is set to .025". Connect the boot assembly to the spark plug terminal. Then lay the spark plug in contact with the muffler as shown. With the ignition switch on, pull the starter rope briskly. A spark should be seen at the spark plug electrode. If not, install a test spark plug and repeat the procedure. A test spark plug can be made by breaking the side electrode off of a new DJ-7J spark plug. If the ignition system can fire a spark across the 1/8" gap, it should fire under compression. If no spark is evident, disconnect the switch lead and repeat test.

NOTE

A solid state module will not produce a spark unless the rotor is turned briskly by the starter assembly. Solid state modules produce an orange "pin-like" spark best seen in the dark. Breaker point ignition systems will produce a heavy blue spark when the rotor is turned by hand.




FIGURE 23

To set the points, turn the crankshaft until the breaker arm rests on the highest point of the crankshaft (known as the cam). Place a .015" shim (Homelite #22486) between the point contacts. The point contacts may be moved after loosening of the two screws that secure them to the engine. After setting the point gap, retighten the two screws. Recheck point gap.




FIGURE 24

To set the air gap between the rotor and module (or coil), loosen the two screws that fasten the module to the cylinder. Rotate the rotor magnets away from the module. Place a .015" shim between the rotor and module core. Rotate the rotor so that the magnets are in line with the module core. Retighten the screws. Recheck gap.

EXHAUST SYSTEM SECTION

Cylinder fins and fan housing should be cleaned occasionally to prevent engine from running too hot.

The muffler should be kept clean and open, but the saw should never be run without the muffler. If local regulations require use of a spark arrestor screen, check condition periodically, and replace when clogged or deteriorated.

While the muffler is off, check the condition of the cylinder ports (and the piston and rings through the ports). If the ports are clogged, it will be necessary to first put the piston to top dead center, then remove carbon carefully with a wooden scraper. Do not scratch the piston or damage edges of the ports.




FIGURE 25

AUTOMATIC OILER SECTION

Two types of automatic oilers have been used in the XL family. One type is the pulse actuated diaphragm pump. The other is a pressure feed system. Below is information useful in troubleshooting both types of systems.

DIAPHRAGM PUMP TYPE OIL SYSTEM




FIGURE 26

Figure 26 is an exploded view of the diaphragm type pump. These parts are not used with the pressure feed system. All XL-2 and Super 2 chain saws use the diaphragm pump. Only the XL chain saws have used either a diaphragm or a pressure feed system.

DIAPHRAGM PUMP TROUBLESHOOTING CHART

NO OIL OUTPUT

Possible Cause

- Oil weight too heavy
- Oil filter plugged
- Atmospheric vent in oil pump cover plugged
- Diaphragm torn or deteriorated
- Diaphragm loose on plunger
- Leak between oil pump cylinder and crankcase
- Exit hole at guide bar pad plugged
- Oil hole in guide bar plugged
- Diaphragm plunger too short
- No spring action in check valve (diaphragm does not spring back when depressed and released).
- Dirt in oil system
- Oil line has fallen off tube fitting in crankcase

Remedy

- Replace with Homelite® Bar and Chain Oil.
- Remove and clean.
- Remove and clean.
- Inspect and replace.
- Replace diaphragm.
- Replace pump cylinder (see Homelite manual #23855-5).
- Remove bar and clean exit hole.
- Remove bar, clean groove and oil hole.
- Correct measurement is .620-.630 (.625 = 5/8").
- Replace check valve (see Homelite manual #23855-5).
- Flush with solvent.
- Reconnect

LOW OIL OUTPUT

Possible Cause

- Oil weight too heavy

Remedy

- Replace with Homelite® Bar and Chain Oil.

Diaphragm Pump Troubleshooting continued on next page.

Diaphragm Pump Troubleshooting *continued*.

Oil filter restricted

Hole in oil inlet line

Oil cap cracked, loose or leaks (tank won't hold pressure)

Tank pressure line blocked or restricted

Duck bill check valve plugged

Connector in pressure line too porous

Diaphragm plunger too long (over .630")

HIGH OIL OUTPUT

Possible Cause

Oil weight too light

Remove, clean and reinstall.

Replace line.

Replace cap.

Clean or replace.

Clean or replace.

Replace connector.

Replace or shorten.

Remedy

Replace with Homelite® Bar and Chain Oil.

PRESSURE FEED OILING SYSTEM

(XL ONLY)

Figure 27 is a diagram of the pressure feed oiling system. The tank is pressurized by air from the crankcase. This pressure forces oil to the guide bar pad.




FIGURE 27

PRESSURE FEED OILING SYSTEM TROUBLESHOOTING CHART

NO OIL OUTPUT

Possible Cause

No pressure coming through pressure line
Duck bill valve not on pressure line
Tank will not hold pressure; hole in tank; oil cap cracked, loose or not sealing
Oil pickup line restricted
Will not oil at idle
Oil filter plugged*
Oil filter check valve not working
Oil line has fallen off crankcase fitting
Guide bar oil hole plugged
Exit hole at guide bar pad plugged

Remedy

Clean line and/or replace duck bill valve.
Install new valve.
Replace necessary parts.
Clean line.
Normal.
Clean filter.
Replace.
Re-connect
Clean
Clean

LOW OIL OUTPUT

Possible Cause

Hole in orifice too small
Restricted oil pickup line
Restricted oil filter
Connector in duck bill valve too porous
Too much connector exposed
Oil weight too heavy in cold weather

Remedy

Correct size 3/64" (.046).
Clean.
Clean.
Replace with connector 69659-B.
Jam duck bill valve against pressure line.
Dilute with kerosene (see owners manual).

HIGH OIL OUTPUT

Possible Cause

Connector in duck bill valve too dense
Duck bill valve jammed tight against pressure line
Hole in orifice too large
Orifice missing

Remedy

Replace with connector 69659-B.
Leave 1/16" gap between valve and pressure line.
Correct size is 3/64" (.046).
Replace

*NOTE: Some saws have oil filters with check valves inside them. Others have screens with no valves.

ENGINE TROUBLESHOOTING

TROUBLESHOOTING CHART

ENGINE FAILS TO START OR STARTS WITH DIFFICULTY

Possible Cause

1. No fuel in tank
2. Switch not on
3. Stale fuel
4. Flooded engine
5. No spark
6. Spark plug fouled
7. Crankcase seals leaking
8. Low compression
9. Exhaust port plugged
10. Improper carburetor adjustment
11. No fuel on spark plug

Remedy

- Fill with clean, fresh fuel mix.
- Push to "RUN" position.
- Fill with clean, fresh fuel mix.
- Remove and clean spark plug.
- Refer to ignition section for spark check.
- Clean and regap spark plug.
- Replace seals.
- Overhaul engine.
- Clean exhaust ports.
- Adjust carburetor (refer to owners manual).
- Fuel not flowing through carburetor.

FUEL NOT FLOWING THROUGH CARBURETOR

Possible Cause

1. Inlet needle stuck
2. Pulse passage blocked
3. Dirt in carburetor
4. Fuel filter
5. Fuel line kinked
6. Torn fuel pump diaphragm
7. Leaking fuel fitting
8. Leaking fuel pump gasket
9. Atmospheric vent on fuel pump cover plugged

Remedy

- Disassemble and clean carburetor. Oil needle before reassembly.
- Clean pulse passage through manifold and carburetor. Check orientation of carburetor and manifold gasket.
- Disassemble and clean.
- Thoroughly clean or replace filter.
- Check routing of fuel line.
- Replace diaphragm.
- Replace fitting.
- Replace gasket.
- Clean cover.

Engine Troubleshooting continued on next page.

ENGINE STARTS AND RUNS BUT DIES OUT WHILE CUTTING

Possible Cause

1. Vent valve in fuel tank restricted
2. Stale fuel causing vaporlock
3. Air leak in engine
4. Fuel line too short
5. Fuel filter hung up in tank
6. Carburetor needs adjusting
7. Ignition failure

Remedy

- Clean or replace.
- Fill tank with clean, fresh fuel mix.
- Check seals.
- Fuel line must be routed properly. Proper length is 7 1/4".
- Filter must reach the tank bottom.
- Adjust carburetor (refer to owners manual).
- Refer to ignition section for spark check.

ENGINE RUNS RICH OR FLOODS

Possible Cause

1. Spark arrestor, muffler or exhaust port restricted
2. Restricted air filter
3. Oil soaked air filter
4. Carburetor inlet needle stuck open
5. Inlet needle lever too high
6. Choke partially open
7. Reed valve damaged or loose

Remedy

- Clean thoroughly.
- Clean or replace.
- Clean or replace.
- Clean needle and seat.
- Reset according to repair manual (Homelite #28855-5).
- Check lever position.
- Check manifold for loose reed rivets.

ENGINE RUNS TOO HOT

Possible Cause

1. Starter housing air inlets restricted
2. Cylinder fins plugged with dirt
3. Stale fuel causing vaporlock
4. Carburetor needs adjusting
5. Spark plug heat range incorrect
6. Air leak in engine
7. Improper amount of oil in fuel mixture
8. Incorrect breaker point gap

Remedy

- Remove and clean housing thoroughly.
- Clean fins thoroughly.
- Fill tank with clean, fresh fuel mix.
- Adjust carburetor (refer to owners manual).
- Install proper spark plug.
- Check seals.
- Fill tank with clean, fresh fuel mix. Check owners manual for proper ratio.
- Reset point gap.

ENGINE MISSES UNDER LOAD

Possible Cause

1. Spark plug fouled
2. Improper spark plug gap
3. Too much fuel at high speed
4. Ignition system shorted out
5. Spark plug wire broken
6. Dirty or worn breaker points
7. Incorrect rotor air gap
8. Breaker point arm sluggish

Remedy

- Clean and regap spark plug.
- Regap spark plug.
- Adjust carburetor.
- Refer to repair manual (Homelite #23855-5) for troubleshooting.
- Replace.
- Replace or clean and gap.
- Adjust air gap.
- Clean and lubricate breaker point arm.

ENGINE LACKS POWER

Possible Cause

1. Restricted air filter
2. Air leak in engine
3. Restricted muffler, exhaust port or spark arrestor screen
4. Low compression
5. Choke partially closed
6. Carburetor needs adjusting
7. Too much oil in fuel mixture

Remedy

- Clean air filter.
- Check crankshaft seals.
- Clean thoroughly.
- Overhaul engine.
- Check lever position.
- Adjust carburetor (refer to owners manual).
- Fill with clean, fresh fuel mix. Refer to owners manual.

Courtesy of Under70ss
Do Not Sell or Reproduce

TORQUE SPECIFICATIONS

COMMON FASTENERS

SIZE & TYPE	LENGTH (mm)	QTY.	APPLICATION	TORQUE LIMITS	
				in.-lbs.	Nm
10-24 X 1 3/4"	44	1	Muffler to cylinder	40-50	4,5 - 5,6
8 X 3/4"	19	2	Module to cylinder	30-40	3,4 - 4,5
10-32 X 2 1/4"	57	2	Carburetor to crankcase	30-40	
10-24 X 1 3/4"	44	1	Muffler to cylinder	40-50	4,5 - 5,6
8 X 3/4"	19	2	Module to cylinder	30-40	3,4 - 4,5
10-32 X 2 1/4"	57	2	Carburetor to crankcase	30-40	3,4 - 4,5
*10-24 X 1/2"	13	4	Engine housing to crankcase	40-50	4,5 - 5,6
8-32 X 1"	25	4	Crankcase to cylinder	40-50	4,5 - 5,6
5/16 - 24 Nut		1	Rotor to crankshaft	100-150	11,3 - 17,0
#6 X 5/16"		2	Shield to cylinder	18-24	2,0 - 2,7
1/4-28 nut		1	Guide bar to crankcase	150-200	17,0 - 22,6
Spark plug		1	To cylinder	120-180	13,6 - 20,3
Clutch		1	To crankshaft	100-150	11,3 - 17,0
5/16 - 24 nut	19	1	Sprocket to crankshaft	100-125	11,3 - 14,1
10 X 3/4" Plastite		1	Pulley to starter housing	30-40	3,4 - 4,5
10-32 X 5/8" self-tap	16	1	Starter housing to engine housing	40-50	4,5 - 5,6

XL (PLASTIC HOUSING)

10 X 3/4"	19	4	Starter housing to engine housing	30-40	3,4 - 4,5
*10 X 5/8"	16	1	Handle cover to engine housing	20	2,3
10 X 3/4"	19	1	Handguard to engine housing	40-50	4,5 - 5,6
**13/64-16 X 3/4"	19	4	Starter housing to engine housing	30-40	3,4 - 4,5
8 X 1/2"	13	4	Handle bar to housings	20	2,3
10-16 hi-lo		2	Plastic handle bar to housings	20-30	2,3 - 3,4
8-32 X 1/2"	13	2	Chain stop to engine housing	20-30	2,3 - 3,4

XL-2, SUPER 2

*6-32 X 3/8"	10	3	Oil pump cover to crankcase	18-24	2,0 - 2,7
8 X 1/2"	13	2	Handle bar to starter housing	20	2,3
10-32 X 5/8"	16	1	Handle bar to engine housing	50-60	5,6 - 6,8
10-32 x 3/4"	19	1	Handguard to engine housing	40-50	4,5 - 5,6

*Require fastener compound Homelite part #23488-C.

**Use to replace #10 x 3/4" (19 mm) screws when original threads are stripped.

ENGINE SPECIFICATIONS

Engine firing timing angle	27° + 2° BTDC, not adjustable
Compression	Low 115 psi (7,9 bars) High 145 psi (10 bars) Taken from new hot engine, below 90 psi (6,2 bars) indicates a problem.
Bore	1 5/16" (33,34 mm) Super 2 1 7/16" (36,51 mm)
Stroke	1 3/16" (30,16 mm)
Displacement	1,6 cu. In. (26 cm ³)
Speed	7,000 rpm cutting, 2900 - 3200 rpm idle, 10,000 no load (approximate)
Spark Plug	Champion DJ-7J (Homelite #68616-S)
Point Gap	.015 (0,4 mm)
Rotor Air Gap	.015 (0,4 mm)
Spark Plug Gap	.025 (0,6 mm)

Courtesy of undee70ss
Do Not Sell or Reproduce

HOMELITE DIVISION OF TEXTRON INC.

14401 Carowinds Boulevard

P.O. Box 7047

Charlotte, N.C. 28217

Courtesy of undee7055
Do Not Sell or Reproduce

HOMELITE **TEXTRON**

Homelite Division of Textron Inc.